

Select the A Band - Press [A/B] to select the A band

Enter VFO mode – Press [VFO] to switch from memory mode to VFO mode.

Enter the frequency you want to program using dial or press the [ENT] key and use the keypad to enter the frequency number.

Enter a tone (if required)

- Press the [F], then [TONE] key
- Rotate the dial until the correct tone value appears on the screen
- Press [OK] to save
- Press [TONE] key until “T” for transmit tone or “CT” for transmit AND receive tone

Save the frequency in a Memory Channel (optional)

- Press the [F], then [MR] key
- Rotate the dial to find a memory channel to store the frequency in
 - ▶ means the channel is being used; > means the channel is available
- Press [OK] to store the frequency

Automatic Repeater Offset Override (optional)

- Press the [F], then [MHz] key, repeatedly until +, - or “ “ (i.e. simplex) appears